

## **SECTION III-02 \_\_\_\_\_ Design Speed and Geometric Guides**

Select the design speed from the appropriate Design Guide in section I-06 of this manual keeping in mind if the project is new construction or reconstruction, (RRR, RRRR or PMRRR). Generally the design speed is the posted speed for rural roadways.

For urban projects the posted and design speeds are generally the same.